




BC-2415P/ 2420P/ 2430P Multi-Stage Battery Chargers User Manual



Keep this manual in a safe place for quick reference at all times.

This manual contains important safety and operation instructions for correct use of the battery charger. Read through the manual And pay special attention to the markings and labels of the charger, battery and any equipment connected into the system.

Pay special attention to these two types of notices used in this manual;

WARNING:

Failure to heed this warning may cause injury to persons and damage to Equipment.

CAUTION:

Failure to observe this warning may result in damage to equipment and improper functioning of the Charger.

WARNING:

- The charger is designed for in-door use. Protect the charger from ingress of water.
- This charger is made to charge only properly sized lead acid batteries.
- Don't recharging non-rechargeable batteries.
- Charging other types of battery or under-sized lead acid batteries may cause fire or explosion.
- Install the charger in accordance with all local codes
- Do not use the charger if it has been dropped or damaged.
- Do not remove casing of the charger, there is no user serviceable parts inside.
- Never attempt to charge a frozen battery
- Never attempt to charge a damaged battery.
- Wear protective goggles and turn your face away when connecting or disconnecting the battery.
- Never place the charger on top of a battery.
- Never smoke, use an open flame, or create sparks near battery or charger during normal charging operation as Batteries may give out explosive gas.
- Do not charge batteries in a sealed enclosure (boxed- in) due to possible explosion of entrapped explosive gas.
- Use of accessories not recommended may cause risk of fire, electric shock or equipment damage.
- Disconnect the mains supply before connecting or disconnecting the links to the battery.
- If the charger does not work properly or if it has been damaged, unplug its AC and DC connection.
- Do not use this charger in connection with any medical device or life support system.

CAUTIONS:

- Refer to battery manufacturer's specific recommended values for battery type settings and float voltage setting.
- Ensure all ventilation ports are not obstructed for efficient fan cooling, keep loose soft material such as paper, cloth, etc. away from the Charger
- During charging, the battery must be placed in a well ventilated area.
- If longer output charging cable are required, make sure the cable diameter is adequate for the Current & Cable length.
- AC source from portable generator:
The VA rating of standard generator should be at least 4 times the maximum rating of the charger. Inverter type generator can have 2 to 3 times the maximum rating of the charger.
- It is recommended that the ac output is stabilized by running the generator for 2-3 minutes before switching on the charger.
- This charger is for stand alone application only, parallel or series connection will cause damage to charger and connected battery or load.

Introduction

Congratulations on purchasing our new Multi-Stage (IU0U) Switching Mode Battery Charger.

This series of advanced chargers use Micro-Processor to control the charging profiles and protective functions. The special charging programs are designed to charge both stand alone battery and battery with connected loads.

Innovative charging profiles blend in with the ever changing “state of charge” of the batteries to give just the right amount of current and voltage so your batteries will not be under or over charged. There are 8 sets of selectable charging profiles specifically designed for a wide range of Wet, Gel, AGM, LiFePO4 and Calcium-Calcium lead acid batteries. There are two user programmable charging profiles for the professional users through USB port by personal computer. In addition, the programmed maintenance charge provides a timely Equalization charge for the Wet lead acid battery and refreshing charge to the sealed batteries.


Almost all the protections are controlled by the Micro-Processor. On start-up, the charger run a series of self-tests on the protective functions, displays and critical components like the cooling fan.

The optional detachable Remote Control Panel provides exceptional monitoring of the batteries, charger output, protection status, hours of operation and etc.

Intended Use:

All Automotive, Marine, Mobile Home, Electric Scooters, Golf Carts, Solar, Deep Cycle, UPS Standby, Industrial & Commercial Applications.

A. Control and Indicators



1. Power Switch
To turn ON and OFF AC power to charger
2. Charger status LED display

Charger ON LED (Green)	: Lights up when power ON
Bulk LED (Red)	: Bulk charging with Constant Current (max.)
Absorption LED (Orange)	: Absorption charging with preset Constant Voltage
Float LED (Green)	: Float charging with preset Constant Voltage
Over Temp LED (Red)	: Lights up when over temperature protection, Flashing when current de-rating
Fault LED (Red)	: Charger malfunction (overload, output short circuit, reverse polarity, output over voltage protection)
3. Programming Port
Factory use only
4. Battery selection switch
For AGM, GEL, LiFePO4, Calcium-Calcium, 2x user define & WET (Flooded) batteries (default at GEL P-1)
5. Charging current selection switch
Current can be selected from 10% to 100%. Details please see the table on front panel. (Default at 100%)
6. USB port
Connect charger to a computer for utilizing 'User define setting' or Data logging upload [See Sec. P]
7. Remote display Port
Connect to accessory HBR-3100 remote display
To remote display the charging voltage & charging status and remote control the charger output ON/OFF & Equalization.
8. Equalization mode selection switch
Can be selected by Manual or Auto
9. Battery Connection/ DC Output Terminal(s)
10. Ventilation Fan
11. Inlet AC socket with Mains fuse holder
12. Temperature Sensor Socket
Connection to Battery Temperature sensor (accessory)
Sensor to increase / decrease charging voltage at low/ high battery temperature

B. Using the charger

1. Check the supplied accessories:
AC cord, Remote Battery temperature sensor, CD (software) & USB cable are with the package.
2. Remove the magnetic dummy remote control panel on the front of the charger to select the battery type and the max. output (charging) current, you may need to pry it open to get a hold the edge of the panel in order to lift it out .
3. Battery Type Selection
Check against the Absorption and Float Voltage with the battery type and specifications given in section **N**.
Make sure the charger is power OFF.
Use a small slot type screw driver to select the battery through Battery Selection Switch (4).

AGM/GEL	: Sealed type (VRLA), AGM-GEL, Maintenance Free, Automotive or Deep Cycle lead acid batteries
WET	: Flooded Type lead acid batteries (to which water can be added) Automotive or Deep Cycle
Calcium-Calcium	: Sealed type (VRLA) Lead Acid batteries with Calcium content Automotive or Deep Cycle
LiFePO4	: Sealed type Lithium Iron Phosphate batteries

The selected battery type can be viewed at the optional remote panel.
4. Warning; ONLY Calcium-Calcium type batteries are to be charged in this mode and only when a boost charge is required (30.2Volts).
No load is to be connected to the battery during this charge mode. Charge through one cycle only then set the battery selector back to The WET setting.

C. Power Level adjustment

End users can Preset the maximum output (charging) current in 10% increments to make the charger suitable for different Battery capacities &/or loading conditions.

Make sure the Main Switch is OFF before adjust the power level.

Use a small slot type screw driver to select the maximum output current via the Charging Current Selection Switch (5).

The selected max. output current can be viewed on the optional remote panel .

Position 0: 100% of the rated current

Position 9: 90% of the rated current

Position 8: 80% of the rated current

Position 7: 70% of the rated current

Position 6: 60% of the rated current

Position 5: 50% of the rated current

Position 4: 40% of the rated current

Position 3: 30% of the rated current

Position 2: 20% of the rated current

Position 1: 10% of the rated current

Recommended Battery Capacity

The extended range of AH capacity is based on the appropriate charging current selection 10% to 100%.

Some battery type can take higher charge current.

When in doubt check with battery manufacturer for recommended charging current.

Charger Model	BC-2415P , 15A	BC-2420P , 20A	BC-2430P , 30A
Battery Capacity	6 AH - 150 AH	8 AH - 200 AH	10 AH - 300 AH

D. Testing the charger with output open circuit (nothing connected to the output terminal)

On power up, the charger will do a self check during which all the LED indicators are on and fan in full speed for a few seconds. Then the Charger On and the Absorption LED are on if charger is checked out OK.

After 5 minute the Float LED will be on and Absorption LED off.

Remark:

You can connect a load to the output terminal and the charger will provide a constant DC source voltage according to the 'Battery type' and available 'Output power' (current) settings selected, (as detailed in Sections B3 and C.)

This feature is handy for caravan installer to check the operation of connected powered appliance or connections.

E. Battery Charger Installation and Connection

Observe the warnings & safety precautions before rushing to install and operate the charger.

Check battery condition, fill up cells for wet battery, clean battery poles.

Secure the battery charger in a well ventilated place, make sure the mounting surface is flat and without soft covering material or loose paper sheet. The air intake is at the bottom and air outlet at the back. Make sure both intake and outlet are not blocked.

Never place charger on top of battery.

Plug in the AC mains and turn on Power Switch. All the indicators on the front panel will lit up, cooling fan spins at full speed for 10 seconds by means of Self-Testing.

After self-test mode the Charger ON LED and either Bulk LED or Absorption LED will be lit initially (depending on the state of the battery).

After 5 minutes, if the battery is in a high state of charge, the charger float LED will be lit, otherwise the charger can stay in either Bulk

Or Absorption mode for longer periods if needed.

Before connecting or disconnecting the charging cable, turn off the Power Switch and unplug AC cord from the mains.

First connect the Battery Chargers Positive (+) terminal to the Battery Positive (+) Post. Then connect the Chargers Negative (-) terminal to the Battery Negative (-) Post.

Make sure all the connections are **clean, secured and tight**. Double check for correct polarity.

Double check again for correct selection of Battery Selection Switch (4) for battery type (default at GEL P-1) and Charging Current Selection Switch (5) for output current setting (default at 100%)

When installed in caravans and similar vehicles, the connection to the supply mains is to be in accordance with national wiring rules.


When charging automotive batteries:

- The battery terminal not connected to the chassis has to be connected first. The other connection is to be made to the chassis, remote from the battery and fuel line. The battery charger is then to be connected to the supply mains;
- After charging, disconnect the battery charger from the supply mains. Then remove the chassis connection and then the battery connection.

F. Normal 4-Stage (IUoU) Charging Operation

The 4-stage IUOU charge algorithm ensures fast, complete and at the same time gentle charging of the lead acid battery.

Charging Profile



Stage 1. THE I-PHASE. The constant current charging, Bulk LED is ON.

Normally the battery is charged at constant maximum current until it rises to the selected Absorption voltage level. The charging voltage changes with the battery voltage.

Soft-Start Bulk Charging:

If at the start of charging, the battery voltage is less than 21V, the bulk charge current is reduced to half of what the charging current selector is set at, until the battery voltage rises to 24V. This soft start charging mode will repeatedly check the voltage every 10 minutes until the battery voltage rises to 24V. If the battery voltage cannot reach 24V after 4 hours, unit will go into fault mode and output is shut off. If this happens it is advisable to disconnect any active heavy load on the battery and make sure the charger is set to maximum output current. To reset the charger, switch it off (>30sec) then on.

Remark:

If the battery keeps the charger at Bulk mode for 12 hours, the charger will automatically switch to Float mode.

Stage 2. THE UO-PHASE. The constant voltage charging, Absorption LED is ON.

Battery Type Selection: Gel P-1: 28.2V/ Gel P-2: 28.6V/ AGM: 28.6V/ LiFePO4: 29.2V/ Wet: 28.8V/ Calcium: 30.2V

When the battery voltage reaches the selected Absorption voltage level, the charging switches to Constant voltage charging (Absorption stage). Charging current will decrease gradually until a pre-set value at which the charger then automatically switches to Float Stage. The max. Absorption time is also controlled by the time in Bulk charge, and battery type selected.

Stage 3. THE UO-PHASE. The constant voltage charging, Float LED is ON.

In Float stage, the battery is full and only takes in the amount of current necessary for maintaining the capacity.

The float voltage is preset according to the type of battery selected by the user. Battery Select Switch (4).

If the charger stays in this mode with charging current less than 5A for over 72 hours. Then the charger will automatically switch into the Standby mode.

Stage 4. THE UO-PHASE. The constant voltage charging, Float LED is ON.

In Standby stage, The charging voltage at this mode will be 4% less than the Float voltage only for maintaining the capacity.

This lower charging voltage level reduces drying out of electrolyte liquid, prolongs the life of an inactive battery.

New Cycle Charge every 21 days

The Charger will start a new charging cycle of Bulk to Absorption to Float every 21 days in either standby or float mode. This new cycle of charging will refresh the battery to prevent separation of the electrolyte & keep the electrode plates in good condition. This automatic New Cycle charge after 21 days is designed to keep the battery in good working condition during long periods of storage of the Caravan/RV or back up battery applications.

Remark:

Charger can give out full selected max current in Float or Standby mode. If battery voltage drops to 25V for approx. 10 minutes in Float or Standby mode: The charger will start a new cycle of charging.

G. STORAGE

If the RV/ etc. is in storage for an extended period of time and no solar panels are available to charge the battery, To help guard against Self-discharge of the Battery;

- Leave the AC power connected & the Battery Charger turned on.

First ENSURE ALL loads are turned OFF or Dis-connected from the Battery.

The charger has an automatic Standby Charge Mode and a 21 day New Cycle charge to take care of the battery in storage.

- Or disconnect the Battery charger from the vehicle battery if the AC Mains is to be disconnected or turned off.

Warning;

Batteries on charge should not be left unattended for extended periods. The charging process & battery condition should be checked regularly.

H. User Define Charging Profiles

Connect the charger to a personal computer through USB port (6) then you can set your own charging configuration.

There are two charging positions allocated to store the preset algorithm's by the user.

(Battery Selection Switch (4) set to position 7 or 8.)

I. Equalization Charging for wet type battery only

Warning: Explosion Hazard

Explosive gases from battery during equalization, extreme care must be exercised.

Caution: Only flooded lead acid battery which must have one complete charge cycle before equalization charge.

Make sure electrolyte level is sufficient. Disconnect all DC load connected to the battery

Exercise extreme care to comply with the above cautions when Auto-Equalization is selected.

Wet lead acid batteries requires periodic higher voltage charging (about 10% over usual absorption voltage) to balance the Voltage of each cell, reverse the high concentration of electrolyte at the bottom and clear up large sulfate crystals on the plates. You can use the Equalization Selection Switch (8) to perform the manual equalization through optional remote display or Auto equalization by charger itself.

Once Auto it is selected, the charger will start Equalization automatically if charger keeps at Float mode for over 21 days.

After entered into this mode, the Absorption indicator will flash. This will put the charger keep Equalization for 240 minutes.

The charger will go to Float once completed.

- Remark:
1. This mode only can be operated at Flooded battery selected (Battery Selection Switch (4) set to positions 1, 9 or 0)
 2. During this mode, operator can press the FUNC button (optional remote display) for 5 seconds to force the charger to Float mode anytime.
 3. Take special precautions as battery will emit explosive gas during equalization charge.

J. Dual bank charging

This feature is for caravans, and vehicles with two separate batteries.

The two batteries must be of same chemical make up and type to avoid over and under charging because only one setting of charging profile for both.

Two batteries are charged simultaneously and the battery with the lowest level gets most share of the current in the Bulk charge stage until it is up to the same voltage level of the second battery (battery with higher initial level).

Both batteries will go to the Absorption and the Float Charge at the same time.

K. Temperature Sensor

Warning:

The temperature sensor must be installed at the Negative Terminal of the battery terminal, In-correctly connecting to the Positive Terminal will damage the charger and the sensor.

The temperature sensor (accessory) is used for optimal charging over a wide ambient temperature range.

The Temperature sensor should be positioned so as not to be affected by any other cooling or heating source.

Plug in the temperature sensor **before** switching on the charger to activate the temperature control function, **Never plug in the Sensor during charging.**

Compensation voltage for this temperature sensor is 20mV/C, the higher the battery temperature, the lower the charging voltage.



When battery temperature reaches 60°C, the charger will shutdown, Fault

and OTP indicator will light up.

L. Cable Size Selection

Wire Size (AWG)	Area (mm ²)	Maximum one-way distance (feet) for 2% Voltage loss (15A)	Maximum one-way distance (feet) for 2% Voltage loss (20A)	Maximum one-way distance (feet) for 2% Voltage loss (30A)
10	5.26	15.3	11.5	6.7
8	8.37	24	18	10.3
6	13.3	38	29	15
4	21.2	60	45	28
2	33.6	96	72	45
1/0	53.5	154	116	73
2/0	67.4	192	144	90
4/0	107	282	212	142

Table: Selection of cable size and length versus current

M. Fault Indications

PROTECTIONS & FAULT INDICATIONS WITH CAUSES

PROTECTION / FAULT	FAULT LED	OTP LED	CHARGER OUTPUT: OFF= No Output	REMOTE CONTROL UNIT & LCD Fault Display	REMARKS
Output power decreases due to high operating ambient temperature	OFF	Flashing	ON At reduced power in 25% step leading to output off high temperature protection see next row	no specific indication for high temperature decreased output	Auto return to full set power gradually as unit temp cools down
charger over heat, OTP protection on	Solid ON	Solid ON	OFF Manual power on off reset after fault cleared	Alarm flash & Buzzer on " Charger High Temp "	
Charger preset to reduced output power	OFF	OFF	ON At reduced output power as selected	Indicates " xx% Power Set "	<i>This is not a fault!! So no specific indication</i>
Battery over heat detected by remote temp sensor at (60°C)	Flashing	Solid ON	OFF Manual power on off reset after fault cleared	Alarm flash & Buzzer on " Bat Over Temp "	
Fan not working or stuck	Flashing	Flashing	OFF Manual power on off reset after fault cleared	Alarm flash & Buzzer on " Fan Fault "	
Output Over Voltage Protection when output voltage is 4% higher than it should be for the battery type and charge stage	Solid ON	OFF	OFF Manual power on off reset after fault cleared	Alarm flash & Buzzer on " Output V High "	To protect battery and load connected.
Overload/ Over Current Protection when output current is 10% higher than the rated maximum level	Solid ON	OFF	OFF Manual power on off reset after fault cleared	Alarm flash & Buzzer on " Overload "	To protect charger
Short Circuit for > 20 sec	Solid ON	OFF	OFF Manual power on off reset after fault cleared	Alarm flash & Buzzer on " Output Shorted "	
Short Circuit for < 20 sec	OFF	OFF	ON Charger returns to normal after fault cleared		
Reverse Polarity Protection (Thermal Fuse)	Solid ON	OFF	OFF Manual Power on off reset after correct fuse replaced	Alarm flash & Buzzer on " WRONG POLARITY "	
Bulk 4 hour soft start timer charging reaches 4 hours because battery voltage is less than 24V for 4 hours.	Solid ON	OFF	OFF Manual Power on off reset. Disconnect or switch off active load, Check & set output to maximum	Alarm flashes & Buzzer on Fault mode shows "DC Voltage Low"	EARLY WARNING for Battery Capacity, load and charger not balanced.

N. Trouble Shooting without remote display panel

PROBLEM	INDICATIONS	POSSIBLE CAUSES	SUGGESTED SOLUTION
Charger does not work	Indicator lights not turn on	No AC power AC input socket fuse blown	Check AC connections are correct Replace with correct AC fuse by qualified electrician
No DC output	Charger - On LED is not on, Float and Fault LEDs are on Charger On LED is on, Fault is on, Bulk is flashing	Output short circuit Over temperature protection triggered Severe over loading charger Reverse polarity connection DC fan locked by foreign object or malfunction Battery is less than 24.0V after 4 hours of soft-start bulk charging.	Check DC connections between charger and battery. Charger can auto reset if remove the fault within 20 seconds. Check air intake vent at bottom of charger is blocked or not. Check charger ambient ventilation. Check battery AH capacity within recommended range Check for correct polarity, replace car blade fuse (6) Check DC fan Disconnect or switch off load connected to battery. Check and set charger output to maximum. Check for faulty battery EARLY WARNING for Battery Capacity, load and charger not balanced.
Battery does not get full charge	All indicator LED work normally and sequentially OTP LED flashing	Bad battery connection Battery type select switch in wrong setting Battery capacity too large Ambient temperature too low Battery has damaged cell or battery is too old Wrong set the lower power level	Check for loose contact, right cable size, cable integrity Recheck battery type and change to correct battery selection Make sure charger rating matches battery capacity Move battery to a room temperature location, or get an optional temperature sensor Replace battery Recheck the current selection switch (5) to correct right setting
Long charging time, float light does not come on even after 12 hours charging time.	Absorption light remains on all the time	Charger internal fault	Return the charger to distributor to repair
Bulk LED is on all the time	Bulk light remains on all the time	Wrong battery type selection Battery is excessively depleted and the soft charging is triggered Battery temperature too high	Check charged battery label and change battery type selection to correct setting Recharge the battery after a day, if bulk light remains after several hours, the battery is most likely damaged and cannot accept charge. Replace battery. Use accessory temperature sensor

O. Specifications

Model		BC-2415P	BC-2420P	BC-2430P
Output	Output (Charge) Voltage Selections	Absorption		Float
	WET	28.8V		27.0V
	LiFePO4	29.2V		27.2V
	AGM	28.6V		26.4V
	GEL 1	28.2V		27.4V
	GEL 2	28.6V		27.6V
	CALCIUM	30.2V		27.6V
	User Define 1	24V - 32V		
	User Define 2	24V - 32V		
	Equalization	31V		
	Maximum Output Charging Current (Continuous)	15A	20A	30A
	Recommended Battery Capacity Range	6 – 150AH	8 – 200AH	10 - 300AH
	Soft Start Bulk Charge			
	Battery Voltage to Trigger (cut-in) Soft Start Bulk Charge Mode	<21.0V		
	Soft Start Bulk Charge Current (Current Limit)	1/2 of the charging current	1/2 of the charging current	1/2 of the charging current
	Ripple and Noise (Peak to Peak)	<200mV	<200mV	<200mV
Efficiency at Maximum Power (230V)	>85%	>85%	>84%	
Dual Bank Charging (Battery must be of same type)	Yes	Yes	Yes	
Input	AC Voltage Range	200 – 240V 50Hz~		
	AC Current at Full Load (230V)	2.5A	3.5A	5.0A
Protection	Overload	90-110% Rated Output Current or 50% Rated Output Current (Soft Charge) Protection Type : Constant Current Limiting, recovers Automatically after Fault Condition is Removed.		
	Short Circuit	Recovers Automatically if Fault Condition is Removed within 20 seconds Otherwise the charger will shutdown until re-start the charger again		
	Reverse Polarity	Car Blade Fuse		
	Over Temperature	Protection Type: Shut Down		
	OVP Output Over Voltage	Yes		
Cooling	Cooling Method	Thermostatic, Variable Speed Fan		
Indicators	4-Stage Battery Charger	Yes		
	Charge Phase Bulk / Absorption / Float	Yes		
	Fault Mode	Yes		
	Over Temp	Yes		
	Charger ON	Yes		
Fuses	AC Fuses at IEC AC Power Socket	T3.15A	T4A	F8A
	DC Car Blade Fuse	30A	30A	25Ax2
Accessories	Supplied Accessories	Remote Temperature sensor, ac cable, spare ac fuse at socket, spare dc fuse, CD Software, USB Cable		
	Optional Accessory	Remote Control Panel (Model:HBR-3100)		
Approvals	Safety : CE: EN 60335 SAA: AS/NZS 60335.1, AS/NZS 60335.2.29 (Include clause 21.102: Vibration Test)	Yes		
	EMC: EN 55014; EMF: EN50366	Yes		
Others	Dimensions and Weight	200x80x260mm ; 3.0kg	200x80x260mm ; 3.0kg	200x80x320mm ; 3.9kg
Remarks	All values are based on the standard ambient temperature 25°C and pressure 0.1Mpa.			

P. Optional Remote Display HBR-3100

Warning:

AC mains supply must be disconnected completely from the battery charger before plugging in of the Remote Display HBR-3100. Otherwise the charger will be damaged.


I. Introduction

The Remote Display comes with 10m extension cable with interconnector.

When the optional remote HBR-3100 is installed, it will display the real time charging stage, voltage & amperage, battery type set, max. power level set, type of fault with alarm, etc and can remote control the output terminal On/OFF, trigger the Equalization charging for wet battery and force charger to float mode.

It can be mounted on BC charger by replacing the dummy cover on the front panel or remotely mounted with 10m extension cable going through the unplugged hole at the front of the dummy panel.

II. Connection



1. 10 Meters Phone Cable
2. In Line Coupler 6P6C
3. HBR-3100 Remote Display Module

- a. Take out the dummy remote panel from charger and remove the black hole plug from the dummy remote panel.



- b. Remote cable through the dummy remote panel's hole.




- c. Plug in the remote cable into the charger remote socket.



- d. Mount back the dummy remote panel on the charger panel.



III. Control and Indicator



1. Output ON/OFF : To switch the charger output ON and OFF. Green LED is illuminated when output is ON.
2. Alarm : Can be silenced or audible by toggling this button, default is audible.
Red LED will illuminate when fault occurred
3. Func. : To toggle charger setting Menu and select scrolling to make display continue to scroll all setting
(See optional remote programming section)
4. Set : To confirm the chosen feature you selected.

IV. Programming using the optional remote

- A. Pressing Func. Button to display “Scrolling” or until any setting you want to display
- B. Pressing Set button to confirm

Remote Panel “Scrolling” Menu Options

1. Charger Name	Display charger model
2. Charger Status	Display Bulk / Absorption / Float
3. Battery Type	Display the battery type selected
4. Fault	Display the “No Fault Found” or Type of fault
5. Bat. Bank 1	Display the charging voltage and current of Bank 1
6. Bat. Bank 2	Display the charging voltage and current of Bank 2 for other models in this series
7. Bat. Bank 3	Display N.A as no Bank 3 for this series of charger
8. Total Run Time	Display units total run time
9. Output Power Level	Display current output level
10. Software Version	Displays the current control software version

Remote Short cut

- 1. Press and hold the SET button for 5 seconds and release the button to enter Equalization mode.
(Equalization selection slide switch on main unit should be selected at manual position)
- 2. Press and hold the Func. button for 5 seconds and release the button to force the charger to Float mode.

V. Fault Indication

- 1. Charger High Temp : Charger over temperature
- 2. Bat Over Temp : Battery temperature over 60°C as detected by remote sensor
- 3. Output V High : Output over voltage
- 4. Overload : Overload (OCP)
- 5. Output Shorted : Output short circuit
- 6. Wrong Polarity : Output reverse polarity
- 7. Fan Fault : Fan stuck or not working
- 8. DC Voltage Low : Bulk 4 hour soft start timer charging reaches 4 hours (Battery is less than 24V)

Q. HBC SOFTWARE INSTALLATION

PLEASE REFER TO THE USER MANUAL IN THE CD FOR INSTALLATION AND APPLICATION PROCEDURE